

Honda Pioneer CV Guards

P/N: EMP-12529

Fits: 2014 Pioneer

Includes:

1. (4) CV Guards (Front and Rear)
2. (17) 1/4-20 x 3/4" Flange Bolts-Black
3. (17) 1/4" Flat Washers-Zinc
4. (17) 1/4-20 Nylon Flange Nuts-Zinc
5. (8) J-Clamp with 45 degree (notched corners) (P/N 9232-01)
6. (6) Rear Clamps (12529-03)
7. (2) Rear "Z" Bracket (12529-04)
8. (1) Logo Sticker

Installation should always be done by a professional mechanic.

Installation:

1. Bolt the front CV Guards to the a-arms using the J-Clamps, bolts, washers, and nylon nuts. There will be four clamps per side. NOTE: You will **not** remove the plastic stock guards.
2. Bolt the rear CV Guards to the rear a-arms using the remaining hardware. The "Z" brackets will go inside of the ends of the arms. The other clamps will go on the front and rear of the arms.

