

Polaris RZR CV Boot / A-Arm Guards (Front and Rear)

P/N 9871-RZCV-AL (aluminum)

and

P/N 9832-RZCV-ST (steel)

Includes:

1. (4) Guards (2 front & 2 rear).
2. (8) Small Clamps (notched corners)
3. (16) 1/4-20 Nylon nuts (zinc)
4. (8) 1/4-20x3/4 Hex Flange Hd
5. (8) 1/4-20x2.25" Hex Flange Hd
6. (16) 1/4 Flat Washers (zinc)



Installation:

Front:

1. Using 1/4-20x3/4 screws, nuts, washers and clamps secure front guards to a-arms. Do not tighten. The washers should go on the outside (bottom) of the guards.
2. Turn steering wheel left and right to make sure wheels do not rub on guards. If they rub slide guards in a little and tighten hardware.



Note: fronts may be easier to install if you remove the front wheels. Although, it is not necessary.

Rear:

1. Using 1/4-20x2.25" bolts, nuts, and washers. Secure guards to the rear a-arms. The bolts will go up through the guards and a-arms. The washer and nuts will go on the top.



Extreme Metal Products, LLC
1-216-267-5335

