

**2009 Ranger CV Boot Guards  
P/N 10416-Aluminum**

**Front & Rear**

**MSRP: \$179.99**



**Includes:**

1. (2) Rear CV Guards (L&R)
2. (2) Filler Guard (L&R)
3. (2) Front CV Guards (L&R)
4. (20) 1/4-20x3/4" Hex Flange Bolt
5. (16) 1/4-20 Nylon Nut (Zinc)
6. (4) Square Tube Bracket
7. (8) 1-1/8" Pipe Clamp (notched)
8. (1) Logo Sticker

**Installation:**

1. Use the pipe clamps, nylon nuts, and 3/4" bolts to secure the front.
2. Use the square tube brackets, nylon nuts, and 3/4" bolts to secure the rear.
3. After installing the rear onto the A-arms. Attach the filler guards with remaining bolts.

**1-216-267-5335**

**2009 Ranger CV Boot Guards  
P/N 10416-Aluminum**

**Front & Rear**

**MSRP: \$179.99**



**Includes:**

1. (2) Rear CV Guards (L&R)
2. (2) Filler Guard (L&R)
3. (2) Front CV Guards (L&R)
4. (20) 1/4-20x3/4" Hex Flange Bolt
5. (16) 1/4-20 Nylon Nut (Zinc)
6. (4) Square Tube Bracket
7. (8) 1-1/8" Pipe Clamp (notched)
8. (1) Logo Sticker

**Installation:**

1. Use the pipe clamps, nylon nuts, and 3/4" bolts to secure the front.
2. Use the square tube brackets, nylon nuts, and 3/4" bolts to secure the rear.
3. After installing the rear onto the A-arms. Attach the filler guards with remaining bolts.

**1-216-267-5335**

**2009 Ranger CV Boot Guards  
P/N 10416-Aluminum**

**Front & Rear**

**MSRP: \$179.99**



**Includes:**

1. (2) Rear CV Guards (L&R)
2. (2) Filler Guard (L&R)
3. (2) Front CV Guards (L&R)
4. (20) 1/4-20x3/4" Hex Flange Bolt
5. (16) 1/4-20 Nylon Nut (Zinc)
6. (4) Square Tube Bracket
7. (8) 1-1/8" Pipe Clamp (notched)
8. (1) Logo Sticker

**Installation:**

1. Use the pipe clamps, nylon nuts, and 3/4" bolts to secure the front.
2. Use the square tube brackets, nylon nuts, and 3/4" bolts to secure the rear.
3. After installing the rear onto the A-arms. Attach the filler guards with remaining bolts.

**1-216-267-5335**

**2009 Ranger CV Boot Guards  
P/N 10416-Aluminum**

**Front & Rear**

**MSRP: \$179.99**



**Includes:**

1. (2) Rear CV Guards (L&R)
2. (2) Filler Guard (L&R)
3. (2) Front CV Guards (L&R)
4. (20) 1/4-20x3/4" Hex Flange Bolt
5. (16) 1/4-20 Nylon Nut (Zinc)
6. (4) Square Tube Bracket
7. (8) 1-1/8" Pipe Clamp (notched)
8. (1) Logo Sticker

**Installation:**

1. Use the pipe clamps, nylon nuts, and 3/4" bolts to secure the front.
2. Use the square tube brackets, nylon nuts, and 3/4" bolts to secure the rear.
3. After installing the rear onto the A-arms. Attach the filler guards with remaining bolts.

**1-216-267-5335**

**2009 Ranger CV Boot Guards  
P/N 10416-Aluminum**

**Front & Rear**

**MSRP: \$179.99**



**Includes:**

1. (2) Rear CV Guards (L&R)
2. (2) Filler Guard (L&R)
3. (2) Front CV Guards (L&R)
4. (20) 1/4-20x3/4" Hex Flange Bolt
5. (16) 1/4-20 Nylon Nut (Zinc)
6. (4) Square Tube Bracket
7. (8) 1-1/8" Pipe Clamp (notched)
8. (1) Logo Sticker

**Installation:**

1. Use the pipe clamps, nylon nuts, and 3/4" bolts to secure the front.
2. Use the square tube brackets, nylon nuts, and 3/4" bolts to secure the rear.
3. After installing the rear onto the A-arms. Attach the filler guards with remaining bolts.

**1-216-267-5335**