

# RZR XP900, 2" Receiver Hitch

## Fits: 2011-12 XP900

P/N: EMP-11081

### Includes:

1. (1) Hitch
2. (2) Trapezoid Shape Washers
3. (4) 3/8 x 1" Flange Bolts
4. (4) 3/8 Flat Washers
5. (4) 3/8 Nylon Nuts
6. (1) EMP Logo Sticker

### Installation:

1. Drill out the top two holes with 13/32" drill for the 3/8" bolts. You are just enlarging the original holes in your frame.
2. Bolt hitch on using the bolts, nuts and washers. You will use the large trapezoid shaped washers on inside of the bottom.



# RZR XP900, 2" Receiver Hitch

## Fits: 2011-12 XP900

P/N: EMP-11081

### Includes:

1. (1) Hitch
2. (2) Trapezoid Shape Washers
3. (4) 3/8 x 1" Flange Bolts
4. (4) 3/8 Flat Washers
5. (4) 3/8 Nylon Nuts
6. (1) EMP Logo Sticker

### Installation:

1. Drill out the top two holes with 13/32" drill for the 3/8" bolts. You are just enlarging the original holes in your frame.
2. Bolt hitch on using the bolts, nuts and washers. You will use the large trapezoid shaped washers on inside of the bottom.



# RZR XP900, 2" Receiver Hitch

## Fits: 2011-12 XP900

P/N: EMP-11081

### Includes:

1. (1) Hitch
2. (2) Trapezoid Shape Washers
3. (4) 3/8 x 1" Flange Bolts
4. (4) 3/8 Flat Washers
5. (4) 3/8 Nylon Nuts
6. (1) EMP Logo Sticker

### Installation:

1. Drill out the top two holes with 13/32" drill for the 3/8" bolts. You are just enlarging the original holes in your frame.
2. Bolt hitch on using the bolts, nuts and washers. You will use the large trapezoid shaped washers on inside of the bottom.



# RZR XP900, 2" Receiver Hitch

## Fits: 2011-12 XP900

P/N: EMP-11081

### Includes:

1. (1) Hitch
2. (2) Trapezoid Shape Washers
3. (4) 3/8 x 1" Flange Bolts
4. (4) 3/8 Flat Washers
5. (4) 3/8 Nylon Nuts
6. (1) EMP Logo Sticker

### Installation:

1. Drill out the top two holes with 13/32" drill for the 3/8" bolts. You are just enlarging the original holes in your frame.
2. Bolt hitch on using the bolts, nuts and washers. You will use the large trapezoid shaped washers on inside of the bottom.

