

Arctic Cat Wild Cat Rear Receiver

Fits: Wild Cat 1000

P/N: EMP-11708



Includes:

1. (1) Rear Receiver
2. (1) Steel Angle
3. (5) 5/16 –18 x 2” Bolts
4. (10) 5/16 Flat Washers
5. (5) 5/16-18 Nylon Nuts

Installation:

Watch the video on our website.

Only to be installed by a professional.

1. Attach the bottom with two bolts, nuts, and washers.
2. Attach the top with the remaining bolts, nuts, and washers. The angle will go behind the tube frame.



Arctic Cat Wild Cat Rear Receiver

Fits: Wild Cat 1000

P/N: EMP-11708



Includes:

1. (1) Rear Receiver
2. (1) Steel Angle
3. (5) 5/16 –18 x 2” Bolts
4. (10) 5/16 Flat Washers
5. (5) 5/16-18 Nylon Nuts

Installation:

Watch the video on our website.

Only to be installed by a professional.

1. Attach the bottom with two bolts, nuts, and washers.
2. Attach the top with the remaining bolts, nuts, and washers. The angle will go behind the tube frame.



Arctic Cat Wild Cat Rear Receiver

Fits: Wild Cat 1000

P/N: EMP-11708



Includes:

1. (1) Rear Receiver
2. (1) Steel Angle
3. (5) 5/16 –18 x 2” Bolts
4. (10) 5/16 Flat Washers
5. (5) 5/16-18 Nylon Nuts

Installation:

Watch the video on our website.

Only to be installed by a professional.

1. Attach the bottom with two bolts, nuts, and washers.
2. Attach the top with the remaining bolts, nuts, and washers. The angle will go behind the tube frame.



Arctic Cat Wild Cat Rear Receiver

Fits: Wild Cat 1000

P/N: EMP-11708



Includes:

1. (1) Rear Receiver
2. (1) Steel Angle
3. (5) 5/16 –18 x 2” Bolts
4. (10) 5/16 Flat Washers
5. (5) 5/16-18 Nylon Nuts

Installation:

Watch the video on our website.

Only to be installed by a professional.

1. Attach the bottom with two bolts, nuts, and washers.
2. Attach the top with the remaining bolts, nuts, and washers. The angle will go behind the tube frame.

