

Polaris Ranger Full Windshield Installation Instructions

P/N 9885

Fits: XP700, 500 4x4, 500 4x2, and 6x6

Includes:

1. (1) Polycarbonate Windshield (p/n 9885-01)
2. (1) Steel Bottom/Stiffener (p/n 9885-02)
3. (14) #10-32x3/4" Truss Hd Screws-Zinc
4. (14) #10-32 Nylon Nut
5. (9) Rubber Coated Straps (p/n BR-8863T22)
6. (1) Edge Trim 57" Long (p/n BR-1120A132)



Installation:

1. Insert the bottom of the metal stiffener into the edge trim gasket provided. The metal stiffener has a little notch to mark the center of the windshield which may help the center the gasket.
2. Using the 10-32 screws and nuts, screw the stiffener to the windshield. Do not install the outer screws yet. You will install these with the rubber coated loops on the next step.
3. Mount the whole assembly to the rail cage using the rubber coated straps and remaining screws and nuts.



Warning: This windshield was designed for off road use only. Using at speeds over 40 mph could result in injury or death. Including hauling your Ranger on a trailer at speeds over 40 mph.