

2011 Commander Winch Mounting Plate

Fits: 800cc and 1000cc Commander

P/N: EMP-10908

Accepts major brand winches up to 4000 lbs.

Includes:

1. (1) Winch Plate
2. (2) 3/8-16 x 1" Flange Bolts (for Fairlead)
3. (2) 5/6x1" Hex Bolt (grade 5)
4. (2) 5/16x2-1/2" Hex Bolt (grade 5)
5. (4) 5/16 Nylon Nut
6. (10) 5/16 Flat Washers
7. (2) 3/4" O.D. x 5/16" ID x 1.125" Spacer (10286)

Installation:

1. Set your parking brake.
2. Remove the black plastic shroud.
3. Install the plate using the 1" bolts in the front (see pic 3). Put a washer on the bottom side where the nut goes.
4. Use the 2-1/2" bolts, spacers, washers and remaining nuts to bolt the rear of the plate to your frame. The bolts will go through both sides of the channel. You will put the spacer and (2) washers on the inside of each channel.
5. Tighten all the bolts.
6. Install your winch using the bolts that came with your winch. You can do this first if you want to.
7. Re-install the plastic shroud.
8. Now, you can mount your fairlead bracket to the winch plate using the 3/8" bolts. Note: the plastic cowling will go between the winch plate and the fairlead bracket. On smaller winches you will have to drill out the holes in the cowling.

