

**RZR XP900 Winch Mount**  
**Fits: 2011 XP900**  
**P/N: 11082**  
**Accepts up to a 4000 lb. Winch**

**Includes:**

1. (1) Winch Plate
2. (1) 6-5/8" Wide Fairlead Bracket
3. (1) 4-7/8" Wide Fairlead Bracket
4. (5) 5/16 x 1" Flange Bolts
5. (5) 5/16 Flat Washers
6. (5) 5/16 Nylon Nut
7. (1) Logo Sticker

**Installation:**

We do have an installation video on our website.

1. Place the plate behind your radiator as shown. The rear (3) bolts will go through the plate and into the holes in the frame. Put the nuts and washers on the bottom.
2. The front bolt will go down through the plate and into the frame. Do not put the nuts on yet.
3. Bolt your fairlead to the correct supplied bracket depending on your model of winch.
4. The fairlead bracket will go under the front of the winch bracket (see picture). Once you have it in place bolt it on with the 5/16" bolts, washers and nuts.
5. Install your winch with the bolts that came with your winch.

