

Mid-Size Ranger Front Bumper

Front Bumper

P/N 10732

Tools Required:

1. 1/2" Socket
2. 9/16" Socket

Includes:

1. (1) Front Bumper
2. (2) Mounting Brackets (LH & RH)
3. (1) Bash Plate
4. (8) 3/8 x 1 Black Carriage Bolts
5. (8) 3/8" Serrated Flange Nuts
6. (1) Logo Sticker

Installation:

1. Remove Stock Bumper and save the hardware.
2. Install the two mounting brackets using the stock bolts. Do not tighten yet.
3. Using the three stock bolts from the bottom of the bumper install the bash plate. Again do not tighten yet.
4. Using the carriage bolts and nuts attach the bumper to the brackets and bash plate. Once you have all the bolts in place go ahead and tighten them.
5. Your winch will go on top. Your winch should come with a fairlead mounting bracket. If not we do offer a fairlead mounting bracket.

