

# “Cooter Brown” RZR Full Belly Skid Set

P/N EMP-10587

Fits: RZR 800 and RZR-S (not 570 or 900)

## Tools:

1. Drill
2. Torx Bit
3. 1/2” Open Wrench
4. 3/8” Socket
5. Allen Wrench

## Includes:

1. (25) 5/-6 x 1” Torx Floorboard Screw
2. (4) 5/16-18 Flange Nut
3. (2) 5/16-18 x 2-1/2” Flat Socket Screw
4. (2) 5/16-18 x 1” Flat Socket Screw
5. (1) 9/32” Drill Bit
6. (2) 5/16” Fender Washer
7. (1) Logo Sticker
8. (1) 1” x 7” Plate with two nuts.

## Installation:

1. Remove the stock plastic skid plate and save the hardware (screws and concave washers).
2. Install the two large skids plates in its place using the stock hardware.
3. Drill a hole in the frame using the center c’sunk holes as a guide. Working your way from the center out drill and insert self tapping screws.
4. Install the rear using the 1”x 7” nut plate and the (2) 5/16 x 1” screws. The nut plate will go inside the frame towards the front. The rear will use the 2-1/2” bolts or the self tapping screws depending on the year of your RZR.
5. The front will install with (3) self tapping and (2) 5/16 x 1” flat socket screws and 5/16” nylon nuts. Starting with the two holes that are already in the frame.

