

2013 Ranger 800EFI Mid-Size, 2010-13 Ranger 400 / 2011-13 Ranger 500 CV Boot Guards P/N 10727-AL (Aluminum)

Includes:

1. (2) Front Guards (LH & RH)
2. (2) Rear Guards (LH & RH)
3. (6) Special Size Round Pipe Clamp
4. (4) Square Clamp
5. (15) 1/4-20 x 1" Flange Hd Bolts
6. (15) 14-20 Nylon Nuts
7. (15) 1/4 Flat Washer

Installation:

Front:

1. Remove the stock plastic guards and save the bolts.
2. Using the stock bolts install the front guards do not tighten yet.
3. Using the round clamps, bolts, washers and nuts (3 per side) attach the guard to the A-arms. You will put the nut and washer on the inside.
4. Turn your wheels and make sure it does not rub and then tighten all bolts.

Rear:

1. Attach the rear guards to the a-arm using the two holes in the small end of the a-arms. See the last photo. Do not tighten yet.
2. Now, using the square clamps, bolts, washers, and nuts (2 per side) repeat the same process as you did on the front guards.
3. Tighten all bolts.

