

RZR XP900 Rocker Kicker with Tree Kickers

P/N: EMP-11136

Fits: 2011 XP900

Tools Required:

1. Torx Head Socket.
2. Cordless Drill.
3. Floor Jack.
4. Jack Stands.

Includes:

1. (2) Rocker Knockers (LH & RH)
2. (17) 5/16" x 1" Torx Floorboard Screw
3. (1) 9/32" Drill Bit.
4. (1) Logo Sticker.

NOTE: Because you are drilling your own mounting holes you may want to shim the rocker away from your plastic rocker with cardboard before drilling your holes. In other words, you do not want the guard to tight against the plastic on the side.

Installation:

1. Set Parking Brake.
2. Jack up the front and set on Jack Stands.
3. Hold one rocker knocker in place and mark at least two holes to be drilled.
4. Drill Holes with drill bit provided.
5. Repeat the process for the remaining holes.
6. Repeat the entire process for the other side.

Note: You will only need (16) Torx Screws. You should have one extra.

