

## Polaris RZR-S CV Boot Guards P/N 10448

### Includes:

1. (2) Front CV Boot Guards (LH & RH)
2. (2) Rear CV Boot Guards (LH & RH)
3. (2) Clamps (radiused corners)
4. (8) 1/4-20x2-1/4 Flange hd Bolt
5. (6) 1/4-20x3/4" Flange hd Bolt
6. (14) 1/4-20 Nylon Nuts
7. (14) 1/4 Flat Washers

### Installation:

#### Front

1. Remove the front wheels
2. Using (2) 3/4" and (1) 2-1/4" long bolts, washers, and nuts. Attach the front guards to the A-arm. You will be putting the bolts through existing holes.

#### Rear

1. Remove the rear wheels.
2. Using the remaining 2-1/4" bolts attach the cv guard to the rear A-arm. You will be using existing holes.
3. Attach the outer end of the guard using the clamps and 3/4" bolts. See the picture.

