

# RZR, RZR-S, and RZR-4 Plow Mounting Bracket

P/N: 11411

Works with EMP Front Bumper too.

## Includes:

1. (1) Mounting Plate 11411-01
2. (1) Hat Shaped Part w/ weldnuts 11411-02
3. (2) Swivel Stops (L & R) 11411-06
4. (4) 5/6 x 1" Flange Head Bolts
5. (3) 3/8" x 1" Flange Bolts
6. (3) 3/8" Flange Nuts
7. (2) 3/4" x 2" Pin (CLIPZ-0750-2000)
8. (2) Hitch Pin Clips
9. (4) 3/4" SAE Flat Washers
10. (1) 11485, Eye Bracket.

## Instructions:

1. Watch video on our website.
2. Read Warning Label on Plow Blade.
3. Bolt the mounting plate to the under the front of your RZR using the hat channel part and the 5/16" bolts. The Channel part will sit on top of your frame behind the differential. Do not tighten yet.
4. Bolt the front of the bracket to your RZR using the 3/8" x 1" Bolts and Flange nuts.
5. The stops will be used with the EMP front bumper. These will stop the bumper from coming up too far and damaging your bumper.. They will install with the 2" pins used to mount the plow frame to the mounting plate (see picture and video).
6. Attach the 11485 Eye Bracket to the center ear on the plow swivel with the remaining 3/8" bolt and nut. You will attach your winch cable to this bracket to raise and lower your plow.

