

Commander 2" Front Receiver

Fits: 2011 Commander

P/N: EMP- 10913

Must be used with the factory winch mount Can-Am P/N 715000658 or EMP P/N 10908.

Includes:

1. (1) Receiver Bracket
2. (2) 5/16 x 1" Bolts (Grade 5)
3. (2) 5/16 Nylon Nuts
4. (4) M8 x 30 mm bolts (Grade 8.8)

Using the 5/16 bolts supplied attach this plate to the underside of your winch mount. Using your stock bolts or the longer bolts supplied bolt through this plate the winch mount and into your winch. More questions? See the install video on our website.

WWW.EXTREMEMETALPRODUCTS.COM



Commander 2" Front Receiver

Fits: 2011 Commander

P/N: EMP- 10913

Must be used with the factory winch mount Can-Am P/N 715000658 or EMP P/N 10908.

Includes:

1. (1) Receiver Bracket
2. (2) 5/16 x 1" Bolts (Grade 5)
3. (2) 5/16 Nylon Nuts
4. (4) M8 x 30 mm bolts (Grade 8.8)

Using the 5/16 bolts supplied attach this plate to the underside of your winch mount. Using your stock bolts or the longer bolts supplied bolt through this plate the winch mount and into your winch. More questions? See the install video on our website.

WWW.EXTREMEMETALPRODUCTS.COM



Commander 2" Front Receiver

Fits: 2011 Commander

P/N: EMP- 10913

Must be used with the factory winch mount Can-Am P/N 715000658 or EMP P/N 10908.

Includes:

1. (1) Receiver Bracket
2. (2) 5/16 x 1" Bolts (Grade 5)
3. (2) 5/16 Nylon Nuts
4. (4) M8 x 30 mm bolts (Grade 8.8)

Using the 5/16 bolts supplied attach this plate to the underside of your winch mount. Using your stock bolts or the longer bolts supplied bolt through this plate the winch mount and into your winch. More questions? See the install video on our website.

WWW.EXTREMEMETALPRODUCTS.COM



Commander 2" Front Receiver

Fits: 2011 Commander

P/N: EMP- 10913

Must be used with the factory winch mount Can-Am P/N 715000658 or EMP P/N 10908.

Includes:

1. (1) Receiver Bracket
2. (2) 5/16 x 1" Bolts (Grade 5)
3. (2) 5/16 Nylon Nuts
4. (4) M8 x 30 mm bolts (Grade 8.8)

Using the 5/16 bolts supplied attach this plate to the underside of your winch mount. Using your stock bolts or the longer bolts supplied bolt through this plate the winch mount and into your winch. More questions? See the install video on our website.

WWW.EXTREMEMETALPRODUCTS.COM

