

XP900 Spare Tire Mounting Bracket

P/N: EMP-11099

Must be used with P/N: EMP-11097 Rear Bumper.

Includes:

1. (1) Spare Tire Rack
2. (2) 3/8-24 Chrome Lug Nut.
3. (2) 3/8" x 1" Flange Bolts.
4. (2) 3/8" Flange Nuts.
5. (1) Logo Sticker



XP900 Spare Tire Mounting Bracket

P/N: EMP-11099

Must be used with P/N: EMP-11097 Rear Bumper.

Includes:

1. (1) Spare Tire Rack
2. (2) 3/8-24 Chrome Lug Nut.
3. (2) 3/8" x 1" Flange Bolts.
4. (2) 3/8" Flange Nuts.
5. (1) Logo Sticker



XP900 Spare Tire Mounting Bracket

P/N: EMP-11099

Must be used with P/N: EMP-11097 Rear Bumper.

Includes:

1. (1) Spare Tire Rack
2. (2) 3/8-24 Chrome Lug Nut.
3. (2) 3/8" x 1" Flange Bolts.
4. (2) 3/8" Flange Nuts.
5. (1) Logo Sticker



XP900 Spare Tire Mounting Bracket

P/N: EMP-11099

Must be used with P/N: EMP-11097 Rear Bumper.

Includes:

1. (1) Spare Tire Rack
2. (2) 3/8-24 Chrome Lug Nut.
3. (2) 3/8" x 1" Flange Bolts.
4. (2) 3/8" Flange Nuts.
5. (1) Logo Sticker

