

Commander Replacement Battery Box

P/N: EMP-11431

Fits: 800 and 1000

Holds a Odyssey PC925L Battery (6-15/16" x 6-7/8" x 4-7/8")

Includes:

1. (1) Battery Box
2. (1) Stainless Steel Battery Strap.
3. (8) 1/4" Flat Washers
4. (8) 1/4" Nylon Nut
5. (2) 1/4" x 1 Tek (self tapping screw)
6. (4) 6"+ Zip Ties



Watch the install video on our website.

WWW.EXTREMEMETALPRODUCTS.COM



Installation:

1. Remove the stock battery box.
2. Remove the electrical parts from the stock box and install them on the new box. You will have to drill out the rivets on the bottom.
3. Remove the bracket that holds the fuse block to the firewall. You will have to drill out the rivets.
4. You will mount the fuse bracket to the round tube to the left of the battery box. You can use either the self-tapping screws or the zip ties provided.
5. Install the new battery box and bolt in place with the nuts and washers provided.
6. You will need to remove the side panel to the left of the steering wheel which exposes the pre-filter. Remove the pre-filter. This will give you access to hook up the wires on top of the battery tray.
7. Hook everything back up and install your new PC925L battery.

