

**RZR Battery Tray**  
**P/N 10108-EMP**  
**Fits: Polaris RZR**  
**9-7/8" x 7-1/8" x 6-3/4"**



Pictured with an Optima  
34/78-980 Red Top

Includes:

1. Battery Tray
2. Top Strap
3. (2) #14 Tek Screws
4. (2) 1/4-20 x 1" Screws –Hex Head
5. (2) 1/4" USS Flat Washers
6. (2) 5/16" Battery Lug #36221

Installation:

1. Using a hack saw. Cut out your old battery tray (see fig)
2. Slide battery tray into area.
3. Secure front with TEK screws (if necessary)
4. Secure strap using 1/4 bolts.
5. Using old bolts from original strap, bolt tray into place



**RZR Battery Tray**  
**P/N 10108-EMP**  
**Fits: Polaris RZR**  
**9-7/8" x 7-1/8" x 6-3/4"**



Pictured with an Optima  
34/78-980 Red Top

Includes:

1. Battery Tray
2. Top Strap
3. (2) #14 Tek Screws
4. (2) 1/4-20 x 1" Screws –Hex Head
5. (2) 1/4" USS Flat Washers
6. (2) 5/16" Battery Lug #36221

Installation:

1. Using a hack saw. Cut out your old battery tray (see fig)
2. Slide battery tray into area.
3. Secure front with TEK screws (if necessary)
4. Secure strap using 1/4 bolts.
5. Using old bolts from original strap, bolt tray into place



**RZR Battery Tray**  
**P/N 10108-EMP**  
**Fits: Polaris RZR**  
**9-7/8" x 7-1/8" x 6-3/4"**



Pictured with an Optima  
34/78-980 Red Top

Includes:

1. Battery Tray
2. Top Strap
3. (2) #14 Tek Screws
4. (2) 1/4-20 x 1" Screws –Hex Head
5. (2) 1/4" USS Flat Washers
6. (2) 5/16" Battery Lug #36221

Installation:

1. Using a hack saw. Cut out your old battery tray (see fig)
2. Slide battery tray into area.
3. Secure front with TEK screws (if necessary)
4. Secure strap using 1/4 bolts.
5. Using old bolts from original strap, bolt tray into place



**RZR Battery Tray**  
**P/N 10108-EMP**  
**Fits: Polaris RZR**  
**9-7/8" x 7-1/8" x 6-3/4"**



Pictured with an Optima  
34/78-980 Red Top

Includes:

1. Battery Tray
2. Top Strap
3. (2) #14 Tek Screws
4. (2) 1/4-20 x 1" Screws –Hex Head
5. (2) 1/4" USS Flat Washers
6. (2) 5/16" Battery Lug #36221

Installation:

1. Using a hack saw. Cut out your old battery tray (see fig)
2. Slide battery tray into area.
3. Secure front with TEK screws (if necessary)
4. Secure strap using 1/4 bolts.
5. Using old bolts from original strap, bolt tray into place

