

Ranger Bulkhead Screen P/N 10282

Fits: 2009+ Polaris Ranger

Includes:

- 1. (1) Bulkhead Screen (10282-01)
- 2. (2) Clamp Bracket (rectangle w/ holes 10282-02)
- 3. (4) 1/4-20x1-1/2" Carriage Bolt
- 4. (2) 1/4-20x2-1/4" Carriage Bolt
- 5. (6) 1/4 Nylon Nut
- 6. (6) 1/4 Flat Washers
- 7. (2) 2" Edge Trim (1120A132)
- 8. (1) LOGO Sticker

Installation:

- 1. Slide edge trim over 2" flanges the sides toward the top of the screen.
- 2. Use 2-1/4" bolts and hardware to secure top.
- 3. Use remaining hardware and clamps bracket to secure bottom.

MSRP: \$179.99



WWW.EXTREMEMETALPRODUCTS.COM
1-216-267-5335

Ranger Bulkhead Screen P/N 10282

Fits: 2009+ Polaris Ranger

Includes:

- 1. (1) Bulkhead Screen (10282-01)
- 2. (2) Clamp Bracket (rectangle w/ holes 10282-02)
- 3. (4) 1/4-20x1-1/2" Carriage Bolt
- 4. (2) 1/4-20x2-1/4" Carriage Bolt
- 5. (6) 1/4 Nylon Nut
- 6. (6) 1/4 Flat Washers
- 7. (2) 2" Edge Trim (1120A132)
- 8. (1) LOGO Sticker

Installation:

- 1. Slide edge trim over 2" flanges the sides toward the top of the screen.
- 2. Use 2-1/4" bolts and hardware to secure top.
- 3. Use remaining hardware and clamps bracket to secure bottom.

MSRP: \$179.99



WWW.EXTREMEMETALPRODUCTS.COM
1-216-267-5335

Ranger Bulkhead Screen P/N 10282

Fits: 2009+ Polaris Ranger

Includes:

- 1. (1) Bulkhead Screen (10282-01)
- 2. (2) Clamp Bracket (rectangle w/ holes 10282-02)
- 3. (4) 1/4-20x1-1/2" Carriage Bolt
- 4. (2) 1/4-20x2-1/4" Carriage Bolt
- 5. (6) 1/4 Nylon Nut
- 6. (6) 1/4 Flat Washers
- 7. (2) 2" Edge Trim (1120A132)
- 8. (1) LOGO Sticker

Installation:

- 1. Slide edge trim over 2" flanges the sides toward the top of the screen.
- 2. Use 2-1/4" bolts and hardware to secure top.
- 3. Use remaining hardware and clamps bracket to secure bottom.

MSRP: \$179.99



WWW.EXTREMEMETALPRODUCTS.COM
1-216-267-5335

Ranger Bulkhead Screen P/N 10282

Fits: 2009+ Polaris Ranger

Includes:

- 1. (1) Bulkhead Screen (10282-01)
- 2. (2) Clamp Bracket (rectangle w/ holes 10282-02)
- 3. (4) 1/4-20x1-1/2" Carriage Bolt
- 4. (2) 1/4-20x2-1/4" Carriage Bolt
- 5. (6) 1/4 Nylon Nut
- 6. (6) 1/4 Flat Washers
- 7. (2) 2" Edge Trim (1120A132)
- 8. (1) LOGO Sticker

Installation:

- 1. Slide edge trim over 2" flanges the sides toward the top of the screen.
- 2. Use 2-1/4" bolts and hardware to secure top.
- 3. Use remaining hardware and clamps bracket to secure bottom.

MSRP: \$179.99



WWW.EXTREMEMETALPRODUCTS.COM
1-216-267-5335