

**John Deer Gator Bulkhead**  
**Fits: HPX 4x4, XUV 620i, XUV 850D**  
**P/N 10433**

Includes:

1. (1) Bulkhead
2. (4) P/N 9881 Quick Connect Clamp
3. (1) Logo Sticker

Installation:

1. Remove thumbscrews and nuts from clamps.
2. Position bulkhead about 1" above the front of the cargo bed. The top flange goes toward the rear of the vehicle.
3. Using the thumbscrews attach the bulkhead to your ROPS. Put the 1/4-20 nylon nuts on last, be careful to over tighten them.
4. After, installation you can easily remove your bulkhead without any tools. Simply, remove the thumbscrew and the clamps remain on your ROPS.



**John Deer Gator Bulkhead**  
**Fits: HPX 4x4, XUV 620i, XUV 850D**  
**P/N 10433**

Includes:

1. (1) Bulkhead
2. (4) P/N 9881 Quick Connect Clamp
3. (1) Logo Sticker

Installation:

1. Remove thumbscrews and nuts from clamps.
2. Position bulkhead about 1" above the front of the cargo bed. The top flange goes toward the rear of the vehicle.
3. Using the thumbscrews attach the bulkhead to your ROPS. Put the 1/4-20 nylon nuts on last, be careful to over tighten them.
4. After, installation you can easily remove your bulkhead without any tools. Simply, remove the thumbscrew and the clamps remain on your ROPS.



**John Deer Gator Bulkhead**  
**Fits: HPX 4x4, XUV 620i, XUV 850D**  
**P/N 10433**

Includes:

1. (1) Bulkhead
2. (4) P/N 9881 Quick Connect Clamp
3. (1) Logo Sticker

Installation:

1. Remove thumbscrews and nuts from clamps.
2. Position bulkhead about 1" above the front of the cargo bed. The top flange goes toward the rear of the vehicle.
3. Using the thumbscrews attach the bulkhead to your ROPS. Put the 1/4-20 nylon nuts on last, be careful to over tighten them.
4. After, installation you can easily remove your bulkhead without any tools. Simply, remove the thumbscrew and the clamps remain on your ROPS.



**John Deer Gator Bulkhead**  
**Fits: HPX 4x4, XUV 620i, XUV 850D**  
**P/N 10433**

Includes:

1. (1) Bulkhead
2. (4) P/N 9881 Quick Connect Clamp
3. (1) Logo Sticker

Installation:

1. Remove thumbscrews and nuts from clamps.
2. Position bulkhead about 1" above the front of the cargo bed. The top flange goes toward the rear of the vehicle.
3. Using the thumbscrews attach the bulkhead to your ROPS. Put the 1/4-20 nylon nuts on last, be careful to over tighten them.
4. After, installation you can easily remove your bulkhead without any tools. Simply, remove the thumbscrew and the clamps remain on your ROPS.

