

Ranger XP900
Hard Coat Full Windshield
P/N: EMP-11898

Includes:

1. (1) Polycarbonate Windshield (11898)
2. (4) Thumbscrews
3. (4) 1/4" ID x 1-1/4" OD Black Washer
4. (4) Mounting Bracket (11898-02)
5. (1) 3/16" x 180" Edge Trim

Installation:

1. Starting in the center of the bottom. Install the edge trim around the outside of the windshield. You will need to cut a "V" into the top corners in order to make the sharp angle. Only cut the u-shape not the bubble part (see top photo). The reason you are starting at the bottom is so if you have a leak at the seam it will not drip on you. The length of the edge trim supplied was a little long so that you can trim it at assembly. You can use a wire cutter to cut the edge trim.
2. Attach the windshield to you cage with the brackets, thumbscrews, and washers. The washers will go on the front to cover the slots.

