

Honda Big Red Half Windshield with Quick Connect Clamps P/N 10350

Includes:

1. (1) Half windshield p/n 10350-01 (12/01/08)
2. (4) center brackets p/n 10332-02
1. (2) Quick Connect Clamps 1-5/8 Tube p/n 10338
2. (4) 1/4-20 Nylon nuts for Quick Clamps
3. (2) M6-16 mm min bolts for center brackets
4. (4) 1/4-20 Thumbscrews

Installation:

1. Remove stock M6 screws from under the hood and attach center brackets using M6 screws supplied (fig 3).
2. Using thumbscrews, quick connect clamps, and 1/4" nuts attach to top quick connect clamps. Note: put the 1/4" nuts on last.

WWW.EXTREMOMETALPRODUCTS.COM



Honda Big Red Half Windshield with Quick Connect Clamps P/N 10350

Includes:

1. (1) Half windshield p/n 10350-01 (12/01/08)
2. (4) center brackets p/n 10332-02
1. (2) Quick Connect Clamps 1-5/8 Tube p/n 10338
2. (4) 1/4-20 Nylon nuts for Quick Clamps
3. (2) M6-16 mm min bolts for center brackets
4. (4) 1/4-20 Thumbscrews

Installation:

1. Remove stock M6 screws from under the hood and attach center brackets using M6 screws supplied (fig 3).
2. Using thumbscrews, quick connect clamps, and 1/4" nuts attach to top quick connect clamps. Note: put the 1/4" nuts on last.

WWW.EXTREMOMETALPRODUCTS.COM



Honda Big Red Half Windshield with Quick Connect Clamps P/N 10350

Includes:

1. (1) Half windshield p/n 10350-01 (12/01/08)
2. (4) center brackets p/n 10332-02
1. (2) Quick Connect Clamps 1-5/8 Tube p/n 10338
2. (4) 1/4-20 Nylon nuts for Quick Clamps
3. (2) M6-16 mm min bolts for center brackets
4. (4) 1/4-20 Thumbscrews

Installation:

1. Remove stock M6 screws from under the hood and attach center brackets using M6 screws supplied (fig 3).
2. Using thumbscrews, quick connect clamps, and 1/4" nuts attach to top quick connect clamps. Note: put the 1/4" nuts on last.

WWW.EXTREMOMETALPRODUCTS.COM



Honda Big Red Half Windshield with Quick Connect Clamps P/N 10350

Includes:

1. (1) Half windshield p/n 10350-01 (12/01/08)
2. (4) center brackets p/n 10332-02
1. (2) Quick Connect Clamps 1-5/8 Tube p/n 10338
2. (4) 1/4-20 Nylon nuts for Quick Clamps
3. (2) M6-16 mm min bolts for center brackets
4. (4) 1/4-20 Thumbscrews

Installation:

1. Remove stock M6 screws from under the hood and attach center brackets using M6 screws supplied (fig 3).
2. Using thumbscrews, quick connect clamps, and 1/4" nuts attach to top quick connect clamps. Note: put the 1/4" nuts on last.

WWW.EXTREMOMETALPRODUCTS.COM

