

John Deer Gator Windshield
P/N 10425
Fits: HPX 4x4, XUV 620i, and 850D

Includes:

1. (1) Top Part (10425-01, Large)
2. (1) Bottom Part (10425-02, Small)
3. (6) Quick Connect Clamp (P/N 9881)
4. (1) Velcro 8" Long (Hook & Loop)
5. (1) 47" Plastic Hinge

Installation:

1. Peel back the PVC paper on both sides where the hinge will be (bottom of the top and top of the bottom). You can peel off the remainder after you have it installed.
2. Install the hinge on to both pieces of the windshield. Use soap and water to make it slide on easier. If you must tap it on use a rubber mallet and tap it gently.
3. Remove the 1/4" nylon nuts from the clamps and set aside.
4. Using the clamps and the thumbscrews. Locate and attach to your ROPS. Once you have it located then you can screw on the nylon nuts being careful not to over tighten them and break them off.
5. Peel back one side of the Velcro and stick to the bottom of the windshield. Then peel off the other side and swing it down to stick to your hood.

