## Kawasaki Teryx-4 Laminated Glass Windshield P/N: EMP-12309

## Includes:

- 1. (1) Top Frame (12309-02)
- 2. (1) Bottom Metal Stiffener (12309-03)
- 3. (14) 1/4-20 x 3/4" Flange Bolts-Black Zinc
- 4. (10) 1/4" Washers-Zinc
- 5. (10) 1/4" Nylon Nuts– Zinc
- 6. (4) Quick Clamps (10230, 1-7/8")
- 7. (1) 1/8" x 52" Edge Trim (bubble on the bottom)
- 8. (2) 1/8" x 3" Edge Trim (bubble on the bottom)
- 9. (3) 1" Wide Hook & Loop (Velcro) x 6" Long
- 10. (1) Hand Operated Wiper.
- 11. (1) Logo Sticker

## This item should be installed by a professional Technician.

## Installation;

- 1. Set the vehicles parking brake.
- 2. Bolt the top window frame to the bottom metal stiffener using the 1/4 bolts, washers, and nuts provided.
- 3. Install the hand operated wiper to the metal frame. The handle will got up on the inside (see picture) You can also adjust the height of the wiper by extending the wiper arm. It just slides. NOTE: after you have the windshield completely installed you should put a thread locker on the little fastener that holds the wiper hand on, so you do not loose it.
- 4. Slide the three pieces of the bottom edge trim onto the bottom of the frame . The short pieces will go on the ends as pictured. These will seal and protect your hood.
- 5. The Hook & Loop will go between the top of your windshield frame and the round tube on our cage. One in the middle and one on each side.
- 6. Loosen the top two nuts (one per side) that hold the cage to the vehicle and slide the windshield frame slots under the nuts and then tighten them back to the vehicle manufactures torque specifications.
- 7. Remove the 1/4" nylon nuts on the Quick Clamps and set aside for now. Using the thumbscrews or remaining bolts attach the clamps and windshield frame to the cage. Once, you have it in the correct location tighten them down. Now, you can put the nylon nuts back on to the Quick Clamps.







