

Commander Top
P/N: EMP-10921
Fits: 2011-12 800cc and 1000cc

Includes:

1. (1) Front Section
2. (1) Rear Section
3. (3) 1/8" x 1" x 48" Gasket
4. (2) 1/8" x 1" x 20" Gasket
5. (11) 1/4-20 x 3/4" Black Flange Bolts
6. (11) 1/4-20 Nylon Nuts
7. (5) 1/4" USS Flat Washers
8. (6) 1/4" x 1-1/4" Black Fender Washers
9. (2) 10-32 x 3/4" Truss Head Screw
10. (2) #10 Rubber Washers
11. (1) Light Housing
12. (1) Water Proof Light
13. (6) 2" dia. Rubber coated Galv. Clamp (band)

Installation:

1. Stick one 48" gasket to the flange on the rear section.
2. Stick the remaining two 48" gaskets to the side bars of your cage.
3. Center and stick the two 20" gaskets to the front and rear bars.
4. Set both sections onto your cage. Bolt them together using the black bolts, small washers, and nuts. Put the washers on the bottom side.
5. Attach your top to the cage using the remaining bolts, bands, black washers and nuts. The large washers will go under the bolt head on the top. The bands wrap around the tube. (under the top)
6. The light will go inside the housing and attach with the 10-32 screws. Use the rubber washers on the top side to seal the holes.



EXTREME METAL PRODUCTS LLC