

Installation Instructions
P/N: 11899
Ranger XP900 Front Bumper

This should only be installed by a professional mechanic.

Note: Mounting more than a 4000 lb winch will void the warranty.

Includes:

1. (1) Bumper
2. (2) Side Brackets (passenger & drivers side)
3. (1) Bash Plate
4. (13) 3/8 x 1" Black Carriage Bolts
5. (4) 3/8" x 1" Flange Head Bolts
6. (16) 3/8" Nylon Nuts
7. (16) 3/8" Flat Washers

Installation:

Note: If you are installing a winch it is easier to put it on the bumper first. Refer to your winch instructions.

1. Remove the stock bumper. Save the two long bolts and nuts.
2. Install the side brackets using (2) carriage bolts, (2) flange bolts, (2) nuts, and (2) washers per side. You will reuse our long stock bolts too. Do not tighten yet.
3. Bolt the bumper to the brackets using (8) carriage bolts, (8) nuts, and (8) washers. Do not tighten yet.
4. Bolt the top of the bash plate **inside** the front bumper using the remaining carriage bolts, nuts and washers.
5. Bolt the bottom of the bash plate using the remaining flange bolts, nuts and washers.
6. Tighten all the bolts.

