

Polaris RZR Winch Mount P/N 9852

Fits: Most winches up to 3500 lbs.

Includes:

- (1) Fairlead mounting bracket
- (2) Winch mounting angles (LH & RH)
- (10) 3/8-16 x .75 min Hex HD bolt (Grade 5)
- (4) 3/8-16 Nylon Nuts

Instructions:

1. Removed front plastic cover. You will have to cut out the front of where the fairlead will mount. There is a break away area built into the plastic. Do this last.
2. Mount the angles with the two holes in the center up. These are where your winch will bolt on (see fig. 3).
3. Mount fairlead bracket to the front using the bolts and nuts supplied (see fig. 4).
4. Mount the fairlead that came with your winch to the bracket (see fig 5).
5. Replace stock plastic front cover.

Extreme Metal Products, LLC
WWW.EXTREMOMETALPRODUCTS.COM
1-216-267-5335

