

**MR10 Hard Coated RZR Cab Back**  
**P/N 11966**  
**Fits: 2008-2013 RZR 800 , 2011-2012 RZR-S**  
**and 2011-2013 RZR 570**

**Includes:**

1. (1) Polycarbonate Back P/N 11966-01
2. (4) P/N 11651 Fast Straps
3. (1) Velcro (hook & loop) 12" for bottom
4. (2) One Wrap Velcro 8"
5. (1) Logo Sticker

**Installation:**

1. Read the cleaning instructions on the protective film on the polycarbonate before removing from both sides.
2. Bolt the Fast Straps to the four slots. Do not tighten them until they are in the correct location.
3. Apply the 12" Velcro to the flange along the bottom. This will keep the bottom from rattling.
4. Secure the middle to the 1-1/2" cross tube with the Velcro One wrap supplied.

