

Polaris RZR XP 900 CV Boot Guards (Fits 2011)

P/N: 11080

Includes:

1. (2) Front CV Boot Guards (LH & RH)
2. (4) Special Size 1" Clamp
3. (2) 1/4-20x2-1/4 Flange hd Bolt
4. (4) 1/4-20x3/4" Flange hd Bolt
5. (6) 1/4-20 Nylon Nuts
6. (6) 1/4 Flat Washers

Installation:

Front

1. Remove the stock plastic guards. These are the flat plastic parts attached with two torx bolts. Save the bolts.
2. Install the guards with the two stock torx bolts. Do not tighten yet.
3. Attach the wide end with the clamps provided. You will use two clamps per side. The clamp will go on the inside of the guard (see picture). The bolts will go up through from the bottom. Do not tighten yet.
4. The long bolt will go up through the outer end and into the cross tube. You can see the hole in the cross tube if you look down from inside. The nut will go on the top.
5. Tighten all the hardware and repeat the process for the other side.

