


P/N 8397-ST
Rhino CV Boot/A-Arm Guard Set
Fits: 450 and 660 Yamaha Rhino

Front:

1. (2) Guards (1 LH and 1 RH)
2. (6) Small Tube Clamps
3. (6) 1/4-20x.75" Button Hd Socket Screw-Zinc
4. (6) 1/4-20 Nylon Nut-Zinc
5. (6) 1/4 Flat Washer

Rear:

1. (2) Guards (1 LH and 1 RH)
2. (4) Large Tube Clamps
3. (4) 1/4-20x.75" Button Hd Socket Screw-Zinc
4. (4) 1/4-20 Nylon Nut-Zinc
5. (4) 1/4 Flat Washer-Zinc
6. (2) 5/16-2.5" Hex Head Bolt-Grade 2 Zinc
7. (2) 5/16 Fender Washer-Zinc
8. (2) 5/16 Nylon Nut-Zinc



Installation:

Front:

1. Using the front hardware install the small front guards on the front A-Arms.
2. The small bent tabs will go toward the wheel. The guard will have the large flange towards the front.
3. Insert the button head screw up through the guard, through the clamp, washer then the nut on top. Repeat this process for the other clamps.
4. Do not tighten the bolts until you make sure the tire does not hit the guards. Turn the steering wheel left and right and if it does not interfere with the tire go ahead and tighten all bolts.

Rear:

1. The large guards will be mounted so that you can read our logo from behind the Rhino.
2. Insert the 2.5" bolts up through the small round hole in the guards. The bolt will go through the A-arm and the large washer and nut will go on top.
3. Using the large clamps, repeat the process used on the front guards.

