

# Polaris Ranger CV Boot Guard Set

## P/N 9341-STEEL

Fits: Ranger 700, with independent suspension

### Includes:

1. (4) Guards (front and rear)
2. (4) Square tube clamps (rear)
3. (6) 1 1/4" pipe clamp (front)
4. (14) 1/4-20 x .75 Button hd cap screw
5. (14) 1/4-20 Nylon nuts
6. (14) 1/4" Flat washers



### Installation Instructions:

#### Front:

1. Remove stock plastic guards (save hardware).
2. Using stock hardware, round pipe clamps, and 1/4-20 hardware, install front guards.

#### Rear:

1. Using the square pipe clamps, and 1/4-20 hardware install the rear guards.

Note: there are two square clamps per side. Two bolts through the holes in the stock a-arms. The notches go towards the front of Ranger.

