

Mule 3010 Front CV Boot Guards
P/N 9651

Includes:

1. (2) CV Boot Guards (LH & RH)
2. (4) Small Clamps (chamfered corners)
3. (4) 1/4-20x 3/4 Flange HD Screw (black zinc)
4. (4) 1/4 Flat Washer (zinc)
5. (4) 1/4 Nylon Nut (zinc)

Instructions:

1. Set Parking Brake.
2. Slip the offset bent end (large end) over front a-arm.
3. Using clamps and hardware secure to a-arm.
One clamp bolts to front flange and the other bolts the bottom of guard.

Suggested Retail: \$74.99

WWW.EXTREMOMETALPRODUCTS.COM

1-800-262-2768

Extreme Metal Products, LLC
Made In USA

