

Kawasaki Teryx Full Belly Skid Set

P/N 10102

Includes:

1. (2) Side Skids
2. (1) Front Skid
3. (1) Rear Skid
4. (1) Center Skid
5. (1) Oil Trap Door
6. (7) #14 x 1" Tek Screw
7. (41) M6x35mm Hex hd screw
8. (43) Concave Washers

Installation:

1. Set vehicle parking brake.
2. Remove Stock Plastic skid plates.
3. Install the front skid plate using M6 screws and concave washer. The two screws nearest the front will not need concave washers.
4. Install the side skids using M6 screws, washers and self tapping screws where there is not a tapped hole. Do not put screws in the holes towards the inside of the vehicle. You will be using these later when you install the center skid.
5. Install the rear skid using the M6 screws and concave washers provided.
6. Install the center skid using the remaining hardware. You will probably have a couple extra screws when you are done.
7. Install the oil trap door using self tapping screws.

1-216-267-5335

