

## Ranger 2" Receiver Plow Mount.

P/N: EMP-10863

Fits: 2009-2011 Ranger XP & Crew.

Does not fit 2009 Crew.

### Includes:

1. (1) P/N 10863 Brkt, Mtg, Plow
2. (6) 3/8-16 x 1" Flange Bolt
3. (5) 3/8 Serrated Flange Nut
4. (1) Hitch Pin 5/8" x 3" Lg

### Installation:

1. Bolt the bracket to the front under side of your vehicle using the bolts and nuts supplied.
2. Use the extra bolt to hold to hold the receiver tight.



## Ranger 2" Receiver Plow Mount.

P/N: EMP-10863

Fits: 2009-2011 Ranger XP & Crew.

Does not fit 2009 Crew.

### Includes:

1. (1) P/N 10863 Brkt, Mtg, Plow
2. (6) 3/8-16 x 1" Flange Bolt
3. (5) 3/8 Serrated Flange Nut
4. (1) Hitch Pin 5/8" x 3" Lg

### Installation:

1. Bolt the bracket to the front under side of your vehicle using the bolts and nuts supplied.
2. Use the extra bolt to hold to hold the receiver tight.



## Ranger 2" Receiver Plow Mount.

P/N: EMP-10863

Fits: 2009-2011 Ranger XP & Crew.

Does not fit 2009 Crew.

### Includes:

1. (1) P/N 10863 Brkt, Mtg, Plow
2. (6) 3/8-16 x 1" Flange Bolt
3. (5) 3/8 Serrated Flange Nut
4. (1) Hitch Pin 5/8" x 3" Lg

### Installation:

1. Bolt the bracket to the front under side of your vehicle using the bolts and nuts supplied.
2. Use the extra bolt to hold to hold the receiver tight.



## Ranger 2" Receiver Plow Mount.

P/N: EMP-10863

Fits: 2009-2011 Ranger XP & Crew.

Does not fit 2009 Crew.

### Includes:

1. (1) P/N 10863 Brkt, Mtg, Plow
2. (6) 3/8-16 x 1" Flange Bolt
3. (5) 3/8 Serrated Flange Nut
4. (1) Hitch Pin 5/8" x 3" Lg

### Installation:

1. Bolt the bracket to the front under side of your vehicle using the bolts and nuts supplied.
2. Use the extra bolt to hold to hold the receiver tight.

