

Kawasaki MULE 4010 Front Receiver Installation Instructions

P/N: EMP-10892

Fits: Mule 4010

Warning: Maximum weight capacity 150 lbs.

Includes:

1. (1) Plate with Receiver welded to it.
2. (1) Angle with threaded fasteners.
3. (6) 3/8 x 1 Flange Bolts (grade 5)
4. (4) 3/8 Flange Nuts
5. (1) Logo Sticker

Tools Required

1. Phillips Screwdriver
2. 9/16 Wrench

Installation:

1. Set the parking brake.
2. Remove front plastic cowling using the Phillips screwdriver.
3. Set the angle in place as shown. The short side goes on top and points toward the rear. Note: you can set this in place but do not fasten until you have the top plate bolted down.
4. Bolt the plate with the receiver on it in place. Bolt the back two bolts first.
5. Now, bolt the angle the your front bumper and to the top plate.
6. Re-install the front plastic cowling.

