

Rhino Diamond Plate Floor Boards

P/N 10045

Includes:

1. (2) Diamond Plate Floor Boards (LH&RH)
2. (18) Pop Rivets (Grip .063-.250, Hold Size 3/16")
3. (18) 1/4x1" Tek Screw

Tools Required:

1. Rivet Gun
2. 3/16" Drill Bit and Drill
3. 3/8" Socket



Installation:

1. Lay the floor boards in their appropriate sides.
2. Attach using the Rivets or Zip Screws.

