

**Can-Am Commander Hard Coat Windshield  
MR-10 Polycarbonate (hard coat on both sides).  
P/N: EMP-10912 (pictured with EMP top)**

Includes:

1. (4) P/N 11651, Patent Pending Rubber Fast Straps.
2. (1) Hard Coat Windshield (1/4" Thick)
3. (1) 1/4" x 50" long Edge Trim
4. (1) Logo Sticker

Installation:

Do not remove the protective coating until installed.

1. Insert edge trim over the bottom of the windshield. Start from the center.
2. Bolt the fast wraps to the windshield. Do not tighten yet.
3. Wrap the straps around your cage and hook on the plastic pins. Now, tighten the hardware.



Extreme Metal Products, LLC

**Can-Am Commander Hard Coat Windshield  
MR-10 Polycarbonate (hard coat on both sides).  
P/N: EMP-10912 (pictured with EMP top)**

Includes:

1. (4) P/N 11651, Patent Pending Rubber Fast Straps.
2. (1) Hard Coat Windshield (1/4" Thick)
3. (1) 1/4" x 50" long Edge Trim
4. (1) Logo Sticker

Installation:

Do not remove the protective coating until installed.

1. Insert edge trim over the bottom of the windshield. Start from the center.
2. Bolt the fast wraps to the windshield. Do not tighten yet.
3. Wrap the straps around your cage and hook on the plastic pins. Now, tighten the hardware.



Extreme Metal Products, LLC

**Can-Am Commander Hard Coat Windshield  
MR-10 Polycarbonate (hard coat on both sides).  
P/N: EMP-10912 (pictured with EMP top)**

Includes:

1. (4) P/N 11651, Patent Pending Rubber Fast Straps.
2. (1) Hard Coat Windshield (1/4" Thick)
3. (1) 1/4" x 50" long Edge Trim
4. (1) Logo Sticker

Installation:

Do not remove the protective coating until installed.

1. Insert edge trim over the bottom of the windshield. Start from the center.
2. Bolt the fast wraps to the windshield. Do not tighten yet.
3. Wrap the straps around your cage and hook on the plastic pins. Now, tighten the hardware.



Extreme Metal Products, LLC

**Can-Am Commander Hard Coat Windshield  
MR-10 Polycarbonate (hard coat on both sides).  
P/N: EMP-10912 (pictured with EMP top)**

Includes:

1. (4) P/N 11651, Patent Pending Rubber Fast Straps.
2. (1) Hard Coat Windshield (1/4" Thick)
3. (1) 1/4" x 50" long Edge Trim
4. (1) Logo Sticker

Installation:

Do not remove the protective coating until installed.

1. Insert edge trim over the bottom of the windshield. Start from the center.
2. Bolt the fast wraps to the windshield. Do not tighten yet.
3. Wrap the straps around your cage and hook on the plastic pins. Now, tighten the hardware.



Extreme Metal Products, LLC