

Maverick Fold-Down Windshield
Fits: 2013 Can-Am Maverick
P/N: EMP-12114

Tools Required:

1. Phillips Screw driver
2. 7/16" Wrench
3. 3/8" Wrench
4. Torx Driver
5. Utility Knife

Includes:

1. (1) Hard Coat Windshield (12114-02)
2. (1) Metal Stiffener (12114-01)
3. (2) Stainless Steel Hold Down Brackets (12114-03)
4. (1) Piano Hinge (47" long)
5. (10) 10-32 x 1/2" Pan Head Phillips-Black
6. (10) 10-32 Nylon Nut
7. (2) Rubber Fast Straps with hardware (11651)
8. (2) Metal Quick Clamps with Thumbscrews (10590)
9. (2) 1/16" x 19" Safety Edge
10. (1) 1/16" x 15" Safety Edge
11. (2) 1/4" x 2" Safety Edge
12. (1) Logo Sticker



Installation:

1. Bolt the hinge to the metal stiffener and the MR10 Polycarbonate. You will use the 10-32 screws and Nylon nuts. See Fig 1. **DO NOT OVER TIGHTEN THE SCREWS, YOU CAN CRACK THE POLY.**
2. Slide the 19" long edge trim over the bottom ends of the metal stiffener. See Fig. 2
3. Slide the 15" long edge trim over the center of them metal stiffener.
4. Remove the Black molding next to the head lights. See Fig. 3.
5. Remove the Torx bolts which are now exposed.
6. Install the Stainless Steel hold down brackets using the stock Torx Bolts. See Fig. 4
7. Cut the lower tab off of the body molding using a utility knife. You will cut one tab off only. See Fig. 5
8. Snap the body molding back on. See Fig. 6
9. Attach the metal stiffener to the cage using the Metal Quick Clamps. The easiest way to do this is to screw the threaded knob through the stiffener and into the metal clamp. Once you have it located on the cage then you can put the 1/4" nylon nuts onto the threaded studs and tighten them with your 7/16" wrench. Note: the purpose of the thumbscrews is so you can remove the windshield without any tools. The clamp will remain on the cage until you install your windshield again. See Fig. 7 and Fig. 8
10. Screw the rubber straps into the top slots in the polycarbonate. The rubber straps will go on the inside of the polycarbonate. The straps will wrap around the cage and hook on the plastic pins when the windshield is up. When folded down they rubber straps will hook onto the stainless steel brackets you installed. See Fig. 9
11. Slide the two remaining pieces of rubber edge trim over the lip on the windshield where it contacts the hood. These will protect the windshield from rubbing on the hood when it is folded down.

