

Can-Am Maverick Hard Coated Full Windshield

P/N: 12121

Fits: 2013 Maverick

Includes:

1. (1) Hard Coat Full Windshield
2. (6) Fast Straps with Hardware (P/N 11651)
3. (2) 1/4" x 14" Long Bubble Edge Trim
4. (1) 1/4' x 18-1/2" Long Bubble Edge Trim
5. (1) Logo Sticker

Tools Required:

1. Phillips Screw Driver
2. 7/16 Socket or Wrench

NOTE: Once the plastic film is removed this item can not be returned.

Installation:

1. Peel back the protective film along the bottom edge on both sides.
2. Slide the three pieces of edge trim over the bottom. The longer piece will go in the center.
3. Attach the Rubber Fast Straps to the windshield. The large washer will go in front of the plastic and the rubber strap on the back side. **DO NOT TIGHTEN YET, LEAVE LOOSE.**
4. Put the windshield on your Maverick and wrap the straps around your cage and fasten to the plastic pins.
5. Not that you have the straps in the correct location you can tighten the bolts and remove the plastic film off both sides.

