

Honda Big Red Full Windshield with quick **Connect Clamps** P/N EMP-10332

Includes:

1. (1) Full Windshield (two parts)
2. (2) Center Brackets with Weld nut p/n 10332-02
3. (6) Quick Connect Clamps for 1-5/8" Tube p/n 10338
4. (12) 1/4 Nylon nuts for Quick Clamps
5. (8) 1/4-20 Thumbscrews
6. (7) 10-32x3/4" Truss head screws for attaching top part of windshield for to bottom part.
7. (7) 10-32 Nylon Nuts
8. (2) M6-16 min bolts for attaching center brackets
9. (1) 1/4" Edge Trim x 57" inches long.

Installation:

1. Slip the edge trim over the bottom of the windshield. Use a rubber mallet to gently tap the trim. Do not remove the protective coating until last.
2. Using 10-32 screws and nuts attach the two windshield pieces together. The top part will go over the bottom so that water will run off. Note: this was made in two pieces to save about a \$80.00 on shipping charges.
3. Open the hood and remove the M6 stock screws. Attach the center brackets with M6 screws supplied (see fig 2).
4. Place windshield on the Big Red. Using the thumbscrews attach the center brackets to the windshield.
5. Now, you have right location. Attach the quick connect clamps. Note: set the 1/4 nylon nuts aside until last.

