

#12772

RZR 900S 2015 A-ARM GUARDS

All installs should be done by a trained professional.

Hardware Included

Front:

1. (2) Front Guards (LH & RH)
2. (4) Clamps (45 degree corners)
3. (8) 1/4-20 x 3/4" Flange Head Bolts
4. (8) 1/4-20 Nylon Flange Nuts

Rear:

1. (2) Rear Guards (LH & RH)
2. (8) 1/4-20 x 2-1/4" Flange Head Bolts
3. (6) 1/4-20 x 3/4" Flange Head Bolts
4. (2) 5/16" USS Flat Washers
5. (14) 1/4 Nylon Nuts
6. (1) Logo Sticker

Installation

Set the parking brake.

Front:

1. Jack up the front and remove the wheels. (**Note:** Guards can be installed without removing the wheels, but this does make the installation considerably more difficult.)
2. Attach the guards to the front a-arms using the clamps and hardware provided. (2) bolts and nuts are to be used in the holes closest to the wheel, and use the clamps and remaining nuts and bolts on the further side. Do not tighten yet.
3. Turn your steering wheel all the way to the right and left and making sure the guards do not rub against the wheels. Adjust if necessary, then tighten the hardware.

Rear:

1. Jack up the rear and remove the wheels.
2. Attach the guards using the longer bolts where necessary (4 per side), and the washers provided for the slotted hole (1 each side). Do not tighten the bolts completely until all are installed and lined up properly. Then tighten all hardware.

