

Directions for P/N 12859 Light Brackets

1. Remove the two factory Torx bolts in the visor.
2. **Drill through the plastic only** with a 3/8" drill bit (you are reaming out the hole in the plastic only, the holes in the cage are already big enough).
3. Bolt the brackets to the cage. The bolts will go down through the plastic and the nut is on the inside. The washers will be used as spacers on top of the plastic. You may want to hold your light bracket in the location to verify you have the brackets going the proper way for your light bar.
4. Do not tighten yet.
5. Mount your light bar to the brackets. The supplied star washers will go between the light bar and the brackets to keep it from easily rotating.
6. Tighten all the hardware.
7. Wire your light bar according to the instructions that came with your light.



EXTREME
METAL PRODUCTS

WWW.EXTREMEMETALPRODUCTS.COM