

## Can-Am Maverick Trail Brush Guard w/winch mount

P/N: 13582

Fits: 2018 Maverick Trail

### Installation Instructions:

#### Includes:

1. (1) Brush Guard (13582-01)
2. (1) Mtg Bracket (13582-02)
3. (1) Cover Plate (13582-05)

Note: If you bought the optional color backer plate it will be packed separately.

#### Hardware Kit:

1. (4) U-Bolts 3/8-16 x 1-3/4"
2. (6) 3/8 -16 x 1" Carriage Bolts
3. (14) 3/8-16 Nylon Flange Nuts
4. (1) Logo Sticker

#### Tools Needed:

1. 3/8" Wrench
2. 3/8" Socket

#### NOTE:

1. Accepts a standard **center** spool winch with a 4-7/8" wide x 3" deep bolt pattern. We recommend the Viper Elite 3500 regular spool winch. These are available on our website.

[WWW.EXTREMOMETALPRODUCTS.COM](http://WWW.EXTREMOMETALPRODUCTS.COM)

1. If you purchased the optional colored backer plate it will go between the bumper and mounting bracket. Set this in place before mounting your brush guard to the bracket.

Installation should be done by a certified technician.

#### Installation:

1. Mount the bracket to the two front tubes. You will want to adjust this up or down to make the front of it perpendicular with the ground. Once you have it in the correct location tighten the nuts.
2. If you are using a winch bolt the winch to the brush guard as shown. Follow the directions that came with your winch at this time.
3. Using the carriage bolts mount the brush guard to the bracket and tighten the nuts.
4. Using the remaining carriage bolts mount the Cover Plate to the frame below to cover the stock winch fairlead location.

