

Polaris RZR Laminated Glass Windshield

P/N: 13830

Fits: 2019 Turbo and 2019 XP1000

Installation Instructions:

Includes:

1. Frame and Windshield

Installation should be done by a certified technician.

Hardware Kit:

1. (4) 1-3/4" Quick Clamps (9881).
2. (4) 1-1/4" OD x 1/4" ID Fender Washer-Black.
3. (4) 1/4-20 x 3/4" Button Head Cap Screw 18-8 Stn Stl. (optional use).
4. (2) 1/2" x 1/4" x 8" Adhesive backed foam strips.
5. (1) 1/2" x 1/4" x 30" Adhesive backed foam strip.
6. (2) 4" Long U-shaped edge trim (TS75B-32).
7. (1) 17-1/2" Long U-shaped edge trim (TS75B-32).
8. (1) Logo Sticker

Installation:

1. Peel the paper off the 8" long strips and apply to the two flanges on the bottom.
2. Peel the paper off the 30" strip and apply to the back side of the top. This will keep the top from rattling.
3. Slide the U-Shaped edge trim over the bottom of the windshield frame. The long part goes in the middle and the short pieces go on the sides of the bottom.
4. Remove the thumb screws and nuts from the quick clamps and set aside for now.
5. Wrap the two part quick clamps around the cage and using the thumbscrews attach the windshield to the clamps.
6. Once, you have the clamps and frame in the correct location put the 10 mm nylon nuts back on the clamps and tighten them. Be sure they are in the correct location because they will not easily come off again.

Tools Needed:

1. 10 mm socket wrench
2. Allen Wrench for optional bolts if used.

Wiper Options sold separately. We offer a hand operated wiper and an electric wiper/washer.

NOTE: The knock outs on the sides are for rearview mirrors.

Thank you, for supporting us.

