

## CF Moto Uforce Laminated Glass Windshield

**P/N: 13862**

**Fits: 2018-2019 500cc and 800cc Models**

### Installation Instructions:

#### Includes:

1. (1) Glass Windshield Frame
2. (1) Hand Wiper (13180-16")

#### Hardware Kit:

1. (4) Quick Clamps w/knobs ( P/N 9881)
2. (8) 1/8" x 1" x 1-1/2" Adhesive Backed Foam Strips
3. (1) 3/32" U-Shaped Edge Trim x 48" Long (BR-TS75B-32)
4. (1) 1/16" x 48" Bubble Edge Trim
5. (2) Rubber Fast Straps (P/N 11651)
6. (1) Logo Sticker

#### Tools Needed:

1. 10mm Socket
2. 17mm Wrench (wiper)
3. Phillips Screwdriver
4. 7/16" Wrench

Installation should be done by a certified technician.

#### Installation:

1. Slide bubble edge trim over the bottom edge.
2. Slide U-Shaped trim over top and sides. If you have a rearview mirror you can cut the trim and remove the knock out along the top.
3. Remove the nuts and thumbscrews from the clamps and set aside for now.
4. Remove the hardware from the rubber fast straps and set aside for now.
5. Apply the adhesive backed foam strips to each side of the metal clamps. This will take up any difference in the diameter and protect your cage.
6. Using the thumbscrews and clamps attach the frame to your cage. Once, you have everything in the correct location put the nylon nuts on the clamps. NOTE: once you tighten the clamps they will not easily come off. Put the nuts on last if need be.
7. Attach the rubber fast straps to the two slots along the tops and wrap around the top tube.
8. Assemble the hand operated wiper to the frame as shown using the 17mm wrench and 10mm socket.

Fig.1



Fig. 5



Fig. 2



Fig. 6



Fig. 3



Fig. 7



Fig 4



Fig. 8

