

# EMP P/N - 13863

CF Moto Uforce 500 & 800 Hard Coated Full Windshield

Fits: 2018-2019 Uforce 500 & 800

## Installation Instructions:

### Includes:

1. (1) Hard Coated Polycarbonate Windshield (13863-01)
2. (1) Slide Vent (13863-02)

### Hardware Kit:

1. (6) Rubber Fast Strap (11651)
2. (2) 1/4-20 x 1" Carriage Bolts
3. (2) Female Knobs 1/4-20 Thread (BRI-F4-B-21)
4. (2) 3/16" x 48" Bubble Edge Trim
5. (1) EMP® Logo Decal

### Tools Needed:

1. (1) Phillips Screwdriver
2. (1) 7/16" Wrench

Installation should be performed by a certified technician.

**NOTE:** Once the protective film is removed, this item can not be returned. Please inspect for scratches and fitment before removing the film. No exceptions.

### Installation:

1. Peel back film to expose the slots where the straps mount, vent area and bottom edge.
2. Slide the bubble edge trim over the top and bottom edges. The top is to keep it from rattling against the factory top.
3. Screw the straps to the windshield. Do not tighten yet.
4. Remove hood. This will make it easier to install.
5. With the help of a friend set the windshield into place. The top flanges will go under the factory top tabs/brackets (two places). This may be a little tight the first installation.
6. Wrap the straps around the cage and hook them back on the plastic pins.
7. Remove the remaining protective film.
8. Using the carriage bolts and Knobs mount the vent to the windshield.
9. Tighten all the hardware.
10. Your installation is complete.

