

CF Moto Uforce Cab Back/Dust Stopper
Hard Coated Cab Back
Fits: Uforce 500 & 800
P/N: 13886

Includes:

1. (1) Hard Coated Cab Back

Hardware Kit:

1. (8) Rubber Fast Straps (11651)
2. (2) 1/8" x 2" Bubble Edge Trim
3. (1) Logo Sticker

Tools Needed:

1. Phillips Screwdriver
2. 7/16 Wrench

Installation should be done by a certified technician.

Installation:

1. Text fit before removing the protective film. Once, the film is removed this item can not be returned.
2. Peel back the protective film exposing the slots and the top edge.
3. Attach the Rubber Fast straps to the cab back using the hardware provided. **DO NOT TIGHTEN YET.**
4. Slide the edge trim pieces over the top, one per side. This will help any rattling if you are using a factory top.
5. Once, you have everything in the correct location tighten all

