

## **Honda Talon Laminated Glass Windshield**

**P/N: 13966**

**Fits: 2020 Talon**

### **Installation Instructions:**

#### **Includes:**

1. (1) Windshield and Frame
2. (1) 12" Hand Wiper (12841)

#### **Hardware Kit:**

1. (2) Vent Plates (1374902 RH & LH)
2. (2) Female Thumbscrews (BR-1.72" Fluted, Female)
3. (4) 2" Rubber Coated Straps (3/4" Wide)
4. (2) Rubber Fast Straps (11651)
5. (4) 1/4" x 1" Truss HD Screws-Black
6. (4) 1-1/4" x 1/4" Fender Washers-Black
7. (4) Nylon Flange Nut-Black
8. (1) 1/16" x 47" Bubble Edge Trim (bubble on the bottom)

#### **Tools Needed:**

1. Phillips Screwdriver
2. 7/16" Wrench

Installation should be done by a certified technician.

#### **Installation:**

1. Inspect your windshield for damage.
2. Remove from box.
3. Slide the Rubber edge trim over the bottom. This will seal and protect the hood.
4. Attach the rubber fast straps to the top two vertical slots. Do not tighten yet.
5. Attach vents to the windshield. You will slide the tab into the slot on the windshield and use the Female Thumbscrew to attach the opposite end. There is a RH and LH vent plate,
6. Attach the windshield to your cage using the rubber straps, screws, washers and nuts. The big washers will go on the outside. Do not tighten yet.
7. Wrap the rubber fast straps around the top horizontal tube.
8. Once, you assured everything is on the correct location tighten the hardware.
9. Install the driver's side wiper following the directions on the wiper.

