Installation Instructions:

Includes:

- 1. (1) Windshield and Frame Assembly (14308-01)
- 2. (1) Hand Wiper (12841)

Hardware Kit:

- 1. (2) Brackets (14308-02)
- (2) 1/4-20 x 1-3/4" Lg. Button Head Screw (Stn Stl)
- 3. (2) 1/4-20 x 3/4" Truss Head Screw-Black
- 4. (2) 1/4-20 x 1-1/4" Lg. Truss Head Screw-Black
- 5. (2) 1/4" x 1-1/4" Fender Washer-Black
- 6. (2) Female Vent Thumbscrews (1.72" dia. Female Thread)
- 7. (2) Rubber Screw Caps-Black
- 8. (6) 1/4" Nylon Flange Nut-Black
- 9. (2) 2" Rubber Coated Straps
- 10.(1) 1/16" x 41" Bubble Edge Trim (Top)
- 11.(1) 1/16" x 52" Bubble Edge Trim (Bottom)
- 12. (2) Aluminum Vent Covers (13749-01, RH & LH)
- 13.(1) Logo Sticker

Tools Needed:

- 1. Phillips Screwdriver
- 2. 7/16" Wrench
- 3. Allen wrench

Installation should be done by a certified technician. Set the parking brake before doing anything.

Installation:

- 1. Inspect parts for damage from shipping. Once, the product has been installed it can not be returned.
- 2. Slide the edge trim over the top and bottom edges. The 41" goes on the top and the 52" goes on the bottom.
- 3. Remove the stock hood and set aside.
- 4. Put the rubber coated straps around the bottom of the cage.
- 5. With the help of a friend set the windshield frame into place.
- 6. Using the brackets and 1-3/4" long screws and nylon nuts attach the top to the cage gusset on the stock cage. Attach the other end of the bracket to the windshield frame with the 3/4" long screws and nylon nuts. Do not tighten yet.
- Using the remaining 1-1/4" screws, nylon nuts and large fender washers attach the bottom to the rubber straps. The large washers will go on the outside. Do not tighten yet.
- 8. Once everything is on place tighten all the hardware and slide the rubber screw caps over the two screws on the bottom.
- 9. Slide the one end of each vent into the slot in the frame and screw the thumbscrews over the studs holding the vents in place.
- 10. Follow the instructions on the hand wiper for installation procedure.















