

## **Yamaha Wolverine RMAX Rear Bumper**

**P/N: 14315**

**Fits: 2021 RMAX 1000**

### **Installation Instructions:**

#### **Includes:**

1. (1) Rear Bumper (12494)
2. (2) Mounting Brackets  
(Passenger and Drivers  
sides)

#### **Hardware Kit:**

1. (4) Stud Plates (3/8" x 1"  
Carriage bolt welded on  
them-Zinc plated)
2. (2) Nut Plates (5/16-18  
Threaded holes-Zinc Plat-  
ed)
3. (4) 3/8" x 1" Carriage  
Bolts-Black
4. (12) 3/8-16" Nylon Nuts-  
Black
5. (4) 5/16"x 1" Flange Bolts-  
Zinc Plated.
6. (1) Logo Sticker

#### **Tools Needed:**

1. 1/2" Wrench
2. 5/8" Wrench

Installation should be done by a certified technician.

#### **Installation:**

1. Inspect parts for shipping damage. Once, parts are installed they can not be returned.
2. Look at the parts diagram and familiarize yourself with the parts.
3. Install the side brackets using two stud plates per side. The stud plates will go into the bed and down through the bumper putting the 3/8" nylon flange nuts on the bottom. Do not tighten yet.
4. Attach the rear of the brackets to the frame using the 5/16" bolts and threaded nut plates. Insert the nut plates in from the rear. It is tight fit. Do not tighten yet.
5. Mount the bumper to the brackets using the carriage bolts and remaining nylon flange nuts.
6. Once, all the hardware is hand tight you can not tighten all the hardware using your wrenches.

There is a video on our website if you need additional help or call us.

